

model	factory model	PCB Part No.	timing	describe
GEA18ESS	JG18B	DG3-98	no change	Three parts : display board & mainboard & power board Setting Temperature : :5-18°C Display : actual temperature & blue colour
GEA45ESS	JG45A	DG3-46	before Mar 29th 2011	Two parts : display board & mainboard Setting Temperature : 5-18°C Display : actual temperature & blue colour
		DG3-99	after Mar 29th 2011	Three parts : display board & mainboard & power board Setting Temperature : :5-18°C Display : actual temperature & blue colour
GEA45TSS	JG45B	DG3-29	before Jan 18th 2011	Two parts : display board & mainboard Setting Temperature : upper zone 5-10°C;lower zone 10-18°C Display : actual temperature & blue colour
		DG3-100-1	after Jan 18th 2011	Two parts : display board & mainboard Setting Temperature : upper zone 5-10°C;lower zone 10-18°C Display : actual temperature & blue colour
GEA2TVS	JG2D	DG3-27	before May 2010	Two parts : display board & mainboard Setting Temperature : left zone 5-18°C;right zone 5-18°C Display : actual temperature & blue colour
GEA2TBS	JG2D	DG3-97	after May 2010	Three parts : display board & mainboard & power board Setting Temperature : left zone 5-18°C;right zone 5-18°C Display : actual temperature & blue colour
GEA166TSS	JG166D	DG3-78.2	no change	Three parts : display board & mainboard & power board Setting Temperature :upper zone 5-18°C;lower zone 5-18°C Display : actual temperature & blue colour